

It is advisable to use three ( 3 ) hinges on a door.

The top hinge needs to be installed close to the top of the door to provide support against door sag.

The center hinge should be installed close as possible to the top hinge for maximum support.

The bottom hinge should be installed at the bottom of the door to provide a pivot point and added closing force if needed.

Note: If using a hollow metal door with the hinge pockets in the standard locations Bommer recommends using 3029-8x4 1/2 hinges for maximum support.

