

USE TIMBERMATE® FOR:

		WOODPUTTY	GRAINFILLER	CRACKFILLER	EDGEFILLER	SANDING SEALER
FURNITURE	Solids - Softwood/Hardwood	✓	✓	✓	✓	✓
	Veneers	✓	✓	✓	✓	✓
PANELLING	Internal	✓	✓	✓	✓	✓
	External	✗	✗	✗	✗	✗
FLOORS	Timber	✓	✓	✓		✓
	Cork	✓	✓	✓		
	Parquetry	✓	✓	✓		✓
TIMBER	Architraves/Skirtings	✓	✓	✓	✓	✓
	Nail holes	✓	✓	✓	✓	✓
	Cracks	✓	✓	✓	✓	✓
	Rebuilding	✓	✓	✓	✓	✓
	Woodturning	✓	✓	✓	✓	✓
	Internal	✓	✓	✓	✓	✓
	External	✗	✗	✗	✗	✗
MDF CRAFTWOOD		✓	✓	✓	✓	✓
PLASTERBOARD		✓		✓		
NOTE		1. All types of stains, coatings & finishes can be used with TIMBERMATE® 2. Use for all types of interior work. ✗ = Not recommended for exterior work. (See Porion for external use) 3. Blank spaces - not usually used				

COLOURS

	BRUSH BOX
	CEDAR (Blackwood)
	EBONY
	HARDWOOD (Ash/Tas Oak)
	JARRAH
	MAHOGANY (Meranti)
	MAPLE
	NATURAL (Tint Base)
	TAS OAK
	PINE
	RIMU (Baltic Pine/Oregon)
	TEAK (Cypress)
	WALNUT
	WHITE

Colours shown are a guide only.

HANDY TIPS FOR THE PERFECT JOB

- Dry with a heat gun or lamp to save drying time.
- Different depths and timbers have different drying times.
- Just wash hands or tools with water to clean up.
- Use on metal, plastic, fibreglass and in foundries.
- Mix in colour prior to applying or apply stain when dry.
- Final colour after coating will be as you see when wet.
- **TIMBERMATE** is ready to sand when colour fades, does not blind sandpaper or sands off like baby powder
- In cold weather, if **TIMBERMATE** hardens, place in sun or stand in tub of hot water to soften.
- Thinning with a little hot water provides best results.

KEEP WAXSTIX ON HAND

TIMBERMATE carry a wide range of coloured wax sticks to repair scratches on timber surfaces. Keep selected colours on hand to keep your timber looking like new.



USE TIMBERMATE® FOR:

		WOODPUTTY	GRAINFILLER	CRACKFILLER	EDGEFILLER	SANDING SEALER
FURNITURE	Solids - Softwood/Hardwood	✓	✓	✓	✓	✓
	Veneers	✓	✓	✓	✓	✓
PANELLING	Internal	✓	✓	✓	✓	✓
	External	✗	✗	✗	✗	✗
FLOORS	Timber	✓	✓	✓		✓
	Cork	✓	✓	✓		
	Parquetry	✓	✓	✓		✓
TIMBER	Architraves/Skirtings	✓	✓	✓	✓	✓
	Nail holes	✓	✓	✓	✓	✓
	Cracks	✓	✓	✓	✓	✓
	Rebuilding	✓	✓	✓	✓	✓
	Woodturning	✓	✓	✓	✓	✓
	Internal	✓	✓	✓	✓	✓
	External	✗	✗	✗	✗	✗
MDF CRAFTWOOD		✓	✓	✓	✓	✓
PLASTERBOARD		✓		✓		
NOTE		1. All types of stains, coatings & finishes can be used with TIMBERMATE® 2. Use for all types of interior work. ✗ = Not recommended for exterior work. (See Porion for external use) 3. Blank spaces - not usually used				

COLOURS

	BRUSH BOX
	CEDAR (Blackwood)
	EBONY
	HARDWOOD (Ash/Tas Oak)
	JARRAH
	MAHOGANY (Meranti)
	MAPLE
	NATURAL (Tint Base)
	TAS OAK
	PINE
	RIMU (Baltic Pine/Oregon)
	TEAK (Cypress)
	WALNUT
	WHITE

Colours shown are a guide only.

HANDY TIPS FOR THE PERFECT JOB

- Dry with a heat gun or lamp to save drying time.
- Different depths and timbers have different drying times.
- Just wash hands or tools with water to clean up.
- Use on metal, plastic, fibreglass and in foundries.
- Mix in colour prior to applying or apply stain when dry.
- Final colour after coating will be as you see when wet.
- **TIMBERMATE** is ready to sand when colour fades, does not blind sandpaper or sands off like baby powder
- In cold weather, if **TIMBERMATE** hardens, place in sun or stand in tub of hot water to soften.
- Thinning with a little hot water provides best results.

KEEP WAXSTIX ON HAND

TIMBERMATE carry a wide range of coloured wax sticks to repair scratches on timber surfaces. Keep selected colours on hand to keep your timber looking like new.

