

# Prime SLIM Soft Closing Drawer PRMSL86/PRMSL118/PRMSL167/PRMSL199

**GALVIN HARDWARE  
PRIME SL INSTALLATION INFO**

### Basic components

### Cutting dimensions of 16mm thick MDF

	H
PRMSL86	86
PRMSL118	118
PRMSL167	167
PRMSL199	199

KB : Cabinet width  
LW : Internal cabinet width  
NL : Nominal length  
H : Back panel height

### Drawer installation to the cabinet.

### Cabinet space requirements

PRMSL86    PRMSL118    PRMSL167    PRMSL199

### Front panel drilling dimensions

	E (min)	F (min)	G (min)	J (min)	K	L
PRMSL86	115				/	/
PRMSL118	150				32	/
PRMSL167	198	33	49	47.5	64	32
PRMSL199	230				64	32

### Front panel adjustment.

Panel left and right adjustment ±1.5mm.  
Panel up and down adjustment ±1.5mm.

### Slide mounting hole distance

Nominal length: 270/300/350/400  
Nominal length: 450/500/550

### The cabinet body rail mounting dimensions

The cabinet front: 37  
Drawer: NL+3  
NL Nominal length

### Drawer disassembly.

The panel is disassembled.

### Drawer installation

1. Attach the slides to the cabinet body.
2. Attach the slides to the drawer box.
3. Attach the back panel to the drawer box.
4. Attach the bottom plate to the drawer box.
5. Attach the front panel to the drawer box using screws SB1900-B, SB1900-C/D. Arrowhead downward (for SB1900-B/C/D).
6. Push the drawer into the cabinet.

### Drawer removal